

## ЗАПЧАСТИ WIRTGEN ФРЕЗА. ФРЕЗА ДОРОЖНАЯ WIRTGEN ЗАПЧАСТИ.



Запчасти для дорожных фрез:

Wirtgen W 1000 F  
Wirtgen W 2000  
Wirtgen W 250 i  
Wirtgen W 220  
Wirtgen W 1900  
Wirtgen W 2200  
Wirtgen W 1500  
Wirtgen W 50 DC  
Wirtgen 2100 D  
Wirtgen W 100 F  
Wirtgen W 130 F  
Wirtgen W 2100  
Wirtgen W 50 Ri  
Wirtgen W 1000 L  
Wirtgen 1000 C  
Wirtgen W 1000  
Wirtgen W 1200 F  
Wirtgen W 120 CF  
Wirtgen W 1300 F  
Wirtgen W 120 F  
Wirtgen W 210 XP  
Wirtgen W 100 CFi  
Wirtgen W 120 Fi  
Wirtgen W 210 i  
Wirtgen W 100 i

Wirtgen W 350 E  
Wirtgen W 350  
Wirtgen W 150  
Wirtgen W 35 DC  
Wirtgen W 150 CF  
Wirtgen W 130 CF  
Wirtgen W 200 Hi  
Wirtgen W 250  
Wirtgen W 60 Ri  
Wirtgen W 100 CF  
Wirtgen W 150  
Wirtgen W 210  
Wirtgen W 60 i  
Wirtgen W 130 Fi  
Wirtgen W 120 CF

## ТЕХНИЧЕСКИЕ ХАРАКТЕРИСТИКИ

99991 BENT PART  
99990 HYDRAULIC HOSE  
99971 STICKER  
9997 TEFLON TAPE  
9996 SEALANT  
99954 HYDRAULIC HOSE  
99953 HYDRAULIC HOSE  
99951 HYDRAULIC HOSE  
99950 HYDRAULIC HOSE  
9995 ADHESIVE  
99949 HYDRAULIC HOSE  
99947 HYDRAULIC HOSE  
99945 HYDRAULIC HOSE  
99944 HYDRAULIC HOSE  
99943 HYDRAULIC HOSE  
99942 HYDRAULIC HOSE  
99935 HYDRAULIC HOSE  
9992 WIRE ROPE  
99909 CLOSING LID  
99898 PIPE BASE PLATE  
99847 BOLT  
99845 BURNT-OUT TEMPLATE  
99765 SUPPORTING SURFACE  
99749 WATER HOSE  
99747 DISTANCE BUSH  
99746 KNURLED NUT  
99744 ALUMINIUM SIGN  
99743 BOWDEN CABLE  
99739 POINTER SHAFT  
99738 SHAFT  
99720 FLOW REGULATOR VALVE  
99707 RETAINING PLATE  
99689 CONTROL STICK  
9968 HYDRAULIC HOSE  
99654 CONDUIT BOX  
99640 SET OF SEALS  
99639 SET OF SEALS  
9961 HEXAGONAL NUT  
99606 STRIP

9958 SCREW  
99562 FOLDING LADDER  
99552 PLATE  
99543 ARMREST  
99541 SCREW  
99540 HYDRAULIC HOSE  
99509 BOLT  
99501 STICKER  
99460 BUTTON BRACKET  
9946 REDUCING RING  
99458 WIRE ROPE  
9943 WORK GLOVES  
99425 WARNING SIGN  
99398 WIPER RUBBER  
99390 MOUNT  
99389 U-LINK 30V AC  
99371 TIMER RELAY  
99327 SCRAPER  
99310 BALL VALVE  
9931 TWIST DRILL  
99292 COVER  
99291 TRAVERSE  
99290 TARPAULIN  
99288 WIPER RUBBER  
99286 SUPPORTING ROLLER  
99285 SUPPORTING ROLLER  
99276 CONNECTING CABLE 24V  
99245 CABLE HARNESS  
99237 STRIP  
99234 ADJUSTER SPINDLE  
99229 THREADED ROD  
9922 LOCKING SCREW  
99214 SUPPORT  
99204 STRUT HT3  
99202 STRUT HT3  
99192 JOYSTICK (CCC)  
99188 STRAP  
99187 BOLT  
99186 FORK HEAD  
99154 SEAL  
99152 SEAL  
99151 SEAL  
99132 COVER  
99127 PIPE SOCKET  
99054 DISTANCE TUBE  
99050 SEAL  
99003 LID  
98978 BOLT  
98977 BOLT  
98939 HOLDER  
98887 TARPAULIN  
98886 TARPAULIN  
98876 HYDRAULIC HOSE  
98875 LID  
98874 FLANGE  
9885 HEXAGONAL NUT  
98845 FLOW METER  
9884 THUMB NUT  
9881 SCREW  
9880 SCREW  
98795 VALVE PLATE  
9879 SCREW  
98782 BITUMEN NOZZLE  
9878 SCREW  
98761 CHAIN WHEEL  
9874 FEATHER KEY  
98739 PIPE

98737 FLANGE  
98720 SOUND ABSORBER  
9872 FEATHER KEY  
98709 PIPE  
98708 PIPE  
98706 ECCENTRIC  
98697 WIRE PROTECTING  
98696 WIRE PROTECTING  
98695 WIRE PROTECTING  
98686 ADJUSTABLE STUD  
98676 SENSOR CABLE  
98665 FLANGED SHAFT  
98664 GROOVED BALL BEARING  
98635 FRONT ELEMENT  
98606 LED-MODULE  
98605 RETAINER CLIP  
98604 RELAY SOCKET  
98595 HYDRAULIC CYLINDER  
98594 HYDRAULIC CYLINDER  
98587 STICKER  
9856 SPLIT PIN  
9855 SPLIT PIN  
9854 SPLIT PIN  
9853 SPLIT PIN  
98524 INSTRUMENT BOARD  
9852 SPLIT PIN  
9851 SPLIT PIN  
98499 SCREW  
9848 SPLIT PIN  
98465 FOOT MAT  
98457 STRAIGHT CONNECTION  
9845 SPLIT PIN  
98439 WEAR SHEET  
98434 WEAR SHEET  
98433 WEAR SHEET  
98432 WEAR SHEET  
9843 SPLIT PIN  
98426 DISPLAY ROD  
98395 SEAL  
98376 V-BELT  
98364 BRAKE LINING  
98363 BRAKE LINING  
98361 NOZZLE EXIT  
98356 GUIDANCE  
98354 SET OF SEALS  
9835 BUSH BEARING  
98349 NOZZLE EXIT  
9834 FEATHER KEY  
98330 BOLT  
98324 MALE STUD COUPLING  
9831 ADAPTER  
98305 CONVEYOR FRAME  
98301 PRESSURE REDUCTION  
98299 CIRCULATION + FEED  
98273 LID  
98271 RELAY MODULE 24V DC  
98267 CHAIN WHEEL  
98255 COUPLING  
98241 PICK SUPPORT HT3  
98234 SUPPORTING ROLLER  
98224 SEALING RUBBER  
98219 ROD END BALL JOINT  
98216 COUPLING  
98204 COVER  
98187 STRIP  
98180 HUB  
9816 CABLE TERMINAL

9814 CABLE TERMINAL  
9813 CABLE TERMINAL  
98127 HINGE  
9810 CABLE TERMINAL  
9809 CABLE TERMINAL  
9807 CABLE TERMINAL  
98066 HYDRAULIC CYLINDER  
98055 BUSHING  
98048 BRUSH STRIP  
98033 REDUCING ADAPTOR  
98003 GAS SPRING  
97996 HYDRAULIC PUMP  
97995 HYDRAULIC PUMP  
97993 TURNBUCKLE SLEEVE  
97989 OVER-CENTER VALVE  
9798 HEXAGONAL NUT  
97966 BELT ROLLER  
9796 CIRCLIP  
97959 ROD END BALL JOINT  
9795 CIRCLIP  
97945 HYDRAULIC CYLINDER  
9794 CIRCLIP  
97907 PLATE  
97901 SCREW  
97894 MECHANICAL BAR  
9789 CIRCLIP  
97882 PUMP SUPPORT  
97880 COUPLING  
97827 PIPE SOCKET  
97825 SAFETY AIR FILTER  
97824 MAIN AIR FILTER  
97813 SEALING RUBBER  
97812 BENT PART  
97811 BELT COVER  
9778 BULB 24V DC  
97765 NILOS RING  
9776 FLAT PLUG SLEEVE  
97735 GROOVED BALL BEARING  
97730 SCREW  
97729 DISTANCE PIECE  
97726 DISTANCE TUBE  
97720 WHEEL  
9772 FLAT PLUG SLEEVE  
97719 RIM  
9771 CRIMP RING CONNECTOR  
9770 CRIMP RING CONNECTOR  
97696 NON-RETURN VALVE  
9769 SCREW  
9768 SCREW  
97676 CHAIN GUIDE  
9766 MANOMETER  
97656 HOUSING  
97655 LID  
97652 HOLDER SYSTEM  
9765 BULB 12V DC  
97649 LID  
97647 SPACER BUSH  
97613 KIT  
97610 SCREW  
97590 FASTENER  
97586 DATA TRANSFORMER  
97585 DATA TRANSFORMER  
97451 GUIDE PLATE  
97441 THREADED PIN  
97433 WHEEL  
97427 TRACK ROLLER  
97426 WHEEL

97415 NOZZLE EXIT  
97412 SIDE PLATE EXTENTION  
97411 SIDE PLATE EXTENTION  
97402 WEAR SHEET  
97384 BEARING FLANGE  
97379 STICKER  
97377 MOVABLE BEARING  
97363 CONVEYOR SUSPENSION  
97314 LOGO BLACK GREY  
97274 T-PIECE  
97273 INSTRUMENT BOARD  
97272 ANGULAR BRACKET  
97256 PIPE  
97250 NOZZLE HOLDER  
97248 NOZZLE  
97246 BOLT  
97243 CONVEYOR BELT B400  
97235 SCRAPER BLADE B 148  
97232 BENT TUBE  
97231 BENT TUBE  
97218 SCREW  
97215 WASHER  
97214 WASHER  
97207 TENSION PULLEY  
97204 RATCHET 3/4"  
97202 COLLECTIVE BLOCK  
97201 FILTER INSERT  
97180 PICK SUPPORT HT2  
97168 NOZZLE  
97153 POWER BELT COMPOUND  
97150 MIXER ARM RH  
97149 MIXER ARM LH  
97148 V-BELT PULLEY  
97147 V-BELT PULLEY  
97146 V-BELT PULLEY  
97092 HOLDER  
97088 REVOLUTION SENSOR  
97087 RUBBER BUFFER  
97074 BOLT  
9704 HYDRAULIC HOSE  
97026 DIRECTIONAL CONTROL  
97017 HYDRAULIC HOSE  
9701 CIRCLIP  
96949 SEALING  
96930 SOUND ABSORBER  
96929 SOUND ABSORBER  
96928 SOUND ABSORBER  
96927 SOUND ABSORBER  
96926 AIR PIPE  
96925 SOUND ABSORBER  
96917 STAY BAR  
96896 SLEWING RING  
96891 HOLDER  
96886 HYDRAULIC MOTOR  
96875 ROLLER CHAIN  
96842 SEAL  
96840 SEAL  
96823 IMPULSE GENERATOR  
96819 KEY  
9681 SEALING NIPPLE  
96802 TIGHTENING STRAP  
96799 PIPE RIVET  
96760 SILENCER  
96755 SILENCER  
96753 SPIRAL CABLE 500V  
96752 SPIRAL CABLE  
9675 PIPE

96728 SUPPORT FOR HOOD  
96727 STRIP  
96669 FOOT MAT  
96616 LOGO BLACK GREY  
96615 LOGO BRIGHT GREY  
96605 PLEATED HOSE  
9659 EJECTION DEVICE  
9658 EJECTION DEVICE  
96568 CRIMP FERRULE WITH  
9656 COUNTER NUT  
9655 COUNTER NUT  
9654 COUNTER NUT  
9653 COUNTER NUT  
96520 BURNT PART  
9652 COUNTER NUT  
96517 FREQUENCY CONVERTER  
96516 FREQUENCY CONVERTER  
96515 FREQUENCY CONVERTER  
96513 BALL VALVE  
96512 THREADED CONNECTOR  
96510 SEALING  
9651 COUNTER NUT  
96509 FLANGE  
96471 SILENCER  
96468 PROTECTING SHEET  
96467 TAIL PIPE  
96464 CONNECTING PIECE  
96457 INTERMEDIATE FRAME  
9643 DUST CAP  
96410 MALE STUD COUPLING  
9639 SPIRAL CABLE  
96368 TANDEM PUMP  
96360 HOLDER  
96358 BOWDEN CABLE  
96357 BOWDEN CABLE  
9634 HYDRAULIC HOSE  
96325 HYDRAULIC MODULE  
96320 GEARBOX  
9632 HYDRAULIC HOSE  
96317 GEARBOX  
9631 HYDRAULIC HOSE  
9630 CRIMP RING CONNECTOR  
96275 SEALING STRIP  
96274 SEALING STRIP  
96257 MALE STUD COUPLING  
96223 HYDRAULIC HOSE  
96222 HYDRAULIC HOSE  
96220 HYDRAULIC HOSE  
96218 HYDRAULIC HOSE  
96199 HYDRAULIC HOSE  
96198 HYDRAULIC HOSE  
96189 TIMER RELAY  
96188 GUIDE SHEET  
96159 HYDRAULIC HOSE  
96158 HYDRAULIC HOSE  
96155 TRANSFORMER  
96152 AIR GUIDANCE  
9612 WIRE FASTENER  
9611 WIRE FASTENER  
9610 WIRE FASTENER  
96089 ENGINE FOOT FRONT  
96088 ENGINE MOUNTING  
9608 CRIMP BUTT SPLICE  
9607 CRIMP BUTT SPLICE  
9606 CRIMP BUTT SPLICE  
9605 CONTACT SLEEVE  
9604 CONTACT SLEEVE

9603 CIRCULAR CONNECTOR  
96026 HYDRAULIC HOSE  
9602 CIRCULAR CONNECTOR  
9601220508 LABEL  
96012 HYDRAULIC HOSE  
96005 HYDRAULIC HOSE  
9600 FLAT PLUG SLEEVE  
9599 FLAT PLUG SLEEVE  
95973 HYDRAULIC PUMP  
95968 SEALING RING PTFE  
95950 STICKER  
95949 CRIMP CONNECTOR  
95948 MODULE INSERT  
95947 FRAME  
95944 PNEUMATIC CYLINDER  
95940 NOZZLE CPL  
95933 SCRAPER  
9590 CABLE (CCC)  
95891 CHANGE PLATINE  
9589 CABLE (CCC)  
95885 CRIMP CONNECTOR  
95884 MODULE  
95883 FRAME  
95881 JOYSTICK  
95880 MULTIFUNCTION  
95877 DUMMY PLUG  
95875 EXTENSION  
95865 DRIVE PULLEY B800  
9586 CABLE (CCC)  
95838 HEATER CARTRIDGE  
95832 SHAFT SEAL  
95826 RING NUT  
95824 SCREW  
95823 SCREW  
95821 MALE STUD COUPLING  
95801 COUPLING  
95782 LID  
95781 PICK SUPPORT HT6  
95780 PROTECTIVE CAP  
95777 FLOW REGULATOR VALVE  
9576 POSITION SWITCH  
95741 RETAINING PLATE  
95715 FLANGE  
9571 TEMPERATURE SWITCH  
95691 GEARBOX  
9569 TEMPERATURE SWITCH  
95687 CONSOLE  
95673 AIR PIPE  
95645 REDUCING COUPLING  
9564 OIL PRESSURE SWITCH  
95610 BOLT  
9560 PLUG SOCKET 24V  
95599 HANDLE  
95597 CONSOLE  
95594 MOVABLE BEARING  
95593 INSULATION PLATE  
95592 INSULATION PLATE  
95591 INSULATION PLATE  
95590 INSULATION PLATE  
9559 IGNITION LOCK  
95584 INSULATION PLATE  
95583 INSULATION PLATE  
95582 INSULATION PLATE  
95581 INSULATION PLATE  
95580 INSULATION PLATE  
9558 BULB 24V DC  
95579 INSULATION PLATE



95578 INSULATION PLATE  
95577 INSULATION PLATE  
95572 TENSION CLAMP  
9556 BULB 24V DC  
95546 HOOK SPANNER  
95518 BOLT  
95515 ARMREST  
9551 SCALE  
95494 HYDRAULIC HOSE  
95471 STRIP  
95465 BENT PART  
95440 BUSHING  
95433 BITUMEN PUMP  
95424 SCREW  
95423 WELDED HEX NUT  
95421 SCREW  
95419 SCREW  
95418 SCREW  
95415 SCREW  
95403 HEXAGONAL NUT  
95400 WELDED HEX NUT  
95399 WELDED HEX NUT  
95396 WASHER  
95384 AIR FILTER ELEMENT  
95383 AIR FILTER INSERT  
95375 RUBBER BEND  
95371 THERMOSTAT  
95367 NUT FOR TRACK PAD  
95366 BOLT FOR BASE PLATE  
95365 AXIAL FACE SEAL  
95363 END BOLT  
95360 PLUG  
95341 SEAL  
95308 SOUND ABSORBER  
95307 V-BELT PULLEY  
95304 VACUUM KIT 24V  
95301 SILENCER  
9530 WELD-ON FITTING  
95288 NOZZLE BAND HEATER  
95285 AXLE  
95278 V-BELT PULLEY  
95265 HOLDER  
9526 CRIMP RING CONNECTOR  
9525 CRIMP RING CONNECTOR  
95248 TURNING POINT  
9524 CRIMP RING CONNECTOR  
95235 ANGLE  
95234 HEX NIPPLE, REDUCING  
9523 CRIMP RING CONNECTOR  
95226 FOOT PROTECTION  
9522 CRIMP RING CONNECTOR  
9521 CRIMP RING CONNECTOR  
95198 DRIVER'S SEAT  
95197 RIM  
9518 WIRE FASTENER  
95179 DIRECTIONAL VALVE  
95166 DRIVE BELT COVER  
95165 DRIVE BELT COVER  
95159 HOLDER  
95138 OIL FILTER CARTRIDGE  
95136 MARKER  
95086 COVERING RUBBER  
95085 COVERING RUBBER  
95018 BITUMEN METERING  
95011 LEVER WITH BOWDEN  
95001 WIRE ROPE  
94990 CYLINDRICAL HOLDING

94985 ROLL HOLDER  
94976 STRIP  
94965 RING PISTON PRESS  
94964 STRIP  
94956 O-RING SEAL  
94938 TRAVERSE  
94908 BALL VALVE  
94907 HYDRAULIC PUMP  
94906 PRESSURE REDUCTION  
94904 DUST GUARD  
94891 LID  
94832 CONE PLUG  
94830 CONE PLUG  
94717 SASH LOCK  
94708 AIR TANK  
94658 INSTRUMENT BOARD  
94657 INSTRUMENT BOARD  
94620 GEARBOX  
94612 GEARBOX  
94611 GEARBOX  
94593 HYDRAULIC MOTOR  
94518 ULTRASONIC SENSOR  
94517 FRONT BEARING  
94479 WHEEL  
94349 HYDRAULIC MOTOR  
94336 ALTERNATOR 28V DC  
94298 GEARBOX  
9423 SASH LOCK  
94228 VARIABLE GAIN  
94224 HYDRAULIC CYLINDER  
9421 HEXAGONAL NUT  
9420 HEXAGONAL NUT  
94189 INPUT/OUTPUT MODULE  
94129 ALTERNATOR 28V DC  
9411 COMPRESSION SPRING  
94024 INSULATION PLATE  
94021 HEXAGONAL NUT  
94017 SEAL  
94016 SEAL  
94014 FLOW DISTRIBUTOR  
94000 GUIDANCE  
93991 TENSIONER ARM  
93965 COVER  
93946 TEST NOZZLE  
93916 COUPLING  
93875 CONTROL BLOCK  
93874 SIDE PLATE LEFT  
93858 TANDEM PUMP  
93851 GUIDE ROLLER  
93850 TRACK ROLLER  
93847 SOLENOID VALVE  
93846 SOLENOID VALVE  
9384 TURNBUCKLE  
93835 BITUMEN PUMP  
93822 SEALING  
9382 TURNBUCKLE  
93819 TWIN NIPPLE  
9381 TURNBUCKLE  
9379 HEXAGONAL NUT  
93766 HEAT RADIATOR  
93747 LOCK  
93739 BOLT  
93737 FLANGE  
93730 SUPPORT  
93714 BENT PART  
93684 GEAR ASSEMBLY KIT  
93681 DUMMY CAP

93680 COUPLING  
93679 COUPLING  
93660 HYDRAULIC HOSE  
93650 BATTERY SUPPORT  
93648 COOLANT TUBE  
93547 SEAL  
93537 AXLE SUSPENSION  
9352 SUPPORT IDLER B1000  
93513 SEAL  
9347 CARRYING ROLLER  
93386 V-BELT PULLEY  
93383 V-BELT PULLEY  
9335 SCREW  
93327 PIPE  
93197 SQUARE PIPE  
93118 COOLING-WATER HOSE  
93097 SOUND ABSORBER  
93096 SOUND ABSORBER  
93045 CONSOLE  
93041 BEARING SHAFT  
93028 SLIDING CONSOLE  
93020 GROOVE NUT  
93010 HYDRAULIC HOSE  
93008 HYDRAULIC HOSE  
93004 SHAFT  
93002 O-RING SEAL  
92999 SCREW  
92997 SCREW  
92996 HOLDER  
92979 O-RING SEAL  
92975 BEARING FLANGE  
92964 FILLER  
92962 RETAINING SHEET  
92961 LID  
92960 BEARING HOUSING  
92959 BEARING SHAFT  
92952 HYDRAULIC HOSE  
9295 PRESSURE-RELIEF  
92933 RETAINING RING  
9288 CRIMP FERRULE WITH  
92873 COARSE GRINDING  
9287 CRIMP FERRULE WITH  
9286 CRIMP FERRULE WITH  
9285 CRIMP FERRULE WITH  
92839 HYDRAULIC MODULE  
92838 HYDRAULIC MODULE  
92820 AXIAL FACE SEAL  
92815 POWER BELT COMPOUND  
92814 V-BELT  
92790 SHAFT  
92768 HYDRAULIC PUMP  
92714 SEALING RUBBER  
92668 GEARBOX  
92633 VIBRATION FORK  
92623 RUBBER BUFFER  
92622 SOUND ABSORBER PLATE  
92621 SOUND ABSORBER PLATE  
92614 COOLING-WATER PIPE  
92613 COOLING-WATER PIPE  
92612 COOLING-WATER PIPE  
92611 COOLING-WATER PIPE  
92610 RUBBER BEND  
92603 HYDRAULIC PUMP  
92602 HYDRAULIC PUMP  
92588 SET OF SEALS  
92542 LEVER  
92541 LEVER

92519 MECHANICAL BAR  
92511 MALE STUD COUPLING  
92495 SPARE PART CPU  
92457 CONVEYOR SUSPENSION  
92453 PUMP SPLITTER  
92447 CONNECTOR HOUSING  
92442 HYDRAULIC HOSE  
92438 PLUG 24V  
92437 THERMOSENSOR  
92436 TEMPERATURE SWITCH  
9237 STRIP  
92366 ADJUSTABLE EQUAL TEE  
92317 CTC DISPLAY 8-32V DC  
92311 PLUG  
9231 DIRECTIONAL VALVE  
9230 HOLDER  
92292 WORM DRIVE HOSE CLIP  
9229 KIT  
9228 HYDRAULIC PUMP  
92272 SET OF SEALS  
92259 RUBBER BEND  
92190 HYDRAULIC HOSE  
92145 CHAIN WHEEL  
92138 SEAL  
92136 PIPE SOCKET  
92101 V-BELT  
92086 PRESSURE-RELIEF  
92085 AUTOMATIC CONTROLLER  
92084 PRESSURE-RELIEF  
92083 SEALING  
92082 SHAFT SEAL  
9201 CRIMP FERRULE WITH  
91978 PROTECTIVE CANVAS  
91967 O-RING SEAL  
91888 AXLE  
91855 WATER NOZZLE  
91853 QUAD-RING VITON  
91823 DRIVER  
91811 HYDRAULIC HOSE  
91799 DUST CAP  
91798 PROTECTING PLUG  
91797 PAD PLATE  
91796 PAD PLATE  
91795 PAD PLATE  
91794 PAD PLATE  
91793 PAD PLATE  
9174 FUSE 36V DC  
9173 FUSE 36V DC  
9172 FUSE 36V DC  
91707 WEDGE  
91706 O-RING SEAL  
91675 V-BELT  
91667 SOUND ABSORBER  
91496 COMPENSATOR TANK  
91495 COMBINED COOLER  
91494 FAN WHEEL  
91493 SOUND ABSORBER PLATE  
91492 SOUND ABSORBER PLATE  
91491 INSULATION PLATE  
91490 SOUND ABSORBER PLATE  
91489 INSULATION PLATE  
91488 SOUND ABSORBER PLATE  
91487 SOUND ABSORBER PLATE  
91485 SOUND ABSORBER PLATE  
91484 SOUND ABSORBER PLATE  
9148 FUSE  
91463 COUPLING

9146 GUIDE PLATE  
91432 CAP  
91429 PROPORTIONAL  
91425 CABLE  
9138 CLOSURE  
9136 THREADED PIN  
9131 BEARING BUSH  
9130 STRIP  
9126 BOLT  
9117 BOLT  
90995 INSULATION PLATE  
90989 GRID  
90982 AIR FILTER  
90981 HOLDER  
90980 AIR FILTER CARTRIDGE  
90973 EXPANDER  
90971 PRINTER 24V  
90944 HYDRAULIC HOSE  
9093 PIPE CLIP  
90915 SLOPE INDICATOR  
90912 HOLDER  
90900 INFO-BOX  
90899 INFO-BOX  
90898 RESISTOR TERMINAL  
90895 O-RING SEAL  
90889 LID  
9087 MALE STUD COUPLING  
90852 SCREW  
90741 PIPE  
90738 CABLE HARNESS  
90733 SUPPORT  
90730 CONNECTION PIPE  
90726 HOLDER  
90725 DISPLAY ROD  
9070 CAP  
90699 STICKER  
90698 STICKER  
90693 EXTENSION CABLE  
90690 HYDRAULIC PUMP  
9069 HINGE  
90680 STUD STANDPIPE  
9067 GREASING NIPPLE  
9066 GREASING NIPPLE  
9065 GREASING NIPPLE  
9064 GREASING NIPPLE  
9063 GREASING NIPPLE  
9062 GREASING NIPPLE  
9061 CUTTING DISC  
9060 COARSE GRINDING  
90591 STICKER  
90590 SCREW  
9059 COARSE GRINDING  
9058 CUTTING DISC  
90532 FLAT STEEL  
90527 SUPPORT SHEET  
90523 PIPE BEND  
90522 HYDRAULIC HOSE  
90521 HYDRAULIC HOSE  
90520 HYDRAULIC HOSE  
90519 HYDRAULIC HOSE  
90515 HYDRAULIC HOSE  
90514 HYDRAULIC HOSE  
90511 ADJUSTABLE EQUAL TEE  
90502 WORM DRIVE HOSE CLIP  
90252 VALVE BLOCK  
90251 BALL VALVE  
90230 PLUG SOCKET 24V

90228 HOUSING  
90227 MICRO CONTROLLER 10  
90226 MULTIFUNCTION  
90224 HYDRAULIC CYLINDER  
90208 DIRECTIONAL VALVE  
90207 LOCKING BAR  
90204 SEALING RUBBER  
90203 BENT PART  
90200 HYDRAULIC OIL FILTER  
90197 RETURN FILTER  
90183 BENT PART  
90182 WIPER RUBBER  
90181 WIPER RUBBER  
90175 TARPULIN  
90173 ENGINE PROTECTION  
90171 CROSS-MEMBER  
90151 SEAL  
90146 SEAL  
90145 BENT PART  
90144 HYDRAULIC PUMP  
90137 JOINT HEAD  
90127 GEARBOX  
90126 BENT PART  
90123 CONVEYOR BELT B600  
90122 SUPPORTING ROLLER  
90121 BELT ROLLER B600  
90120 SUPPORTING ROLLER  
90119 DISCHARGE BIN  
90117 DRIVE PULLEY B600  
90116 SIDE PART  
90107 WIPER RUBBER  
90106 MOUNTING FIXTURE  
90105 WIPER RUBBER  
90103 WIPER RUBBER  
90102 SEALING RUBBER  
90097 SIDE PART  
90096 FEATHER KEY  
90095 FEATHER KEY  
90093 SEAL  
90092 SEAL  
90090 FLANGED SHAFT  
90073 BENT PART  
90071 BENT PART  
90067 RETAINING SHEET  
90062 INTERMEDIATE FLANGE  
9006 SET OF SEALS  
90059 RETURN PULLEY B600  
90058 ROLL HOLDER  
90057 ROLL HOLDER  
90056 ROLL HOLDER  
90051 HYDRAULIC MOTOR  
90049 PIPE  
90048 PIPE  
90047 PIPE  
90042 V-BELT PULLEY  
90040 WHEEL  
90020 FOLDING CONVEYOR  
9000 HOSE  
8995 PLUG  
8994 FEMALE PLUG  
8993 FEMALE PLUG  
89914 FREQUENZGENERATOR  
89900 ELECTRICAL TEST KIT  
89898 TEST PIN  
89897 TEST PIN  
89891 SWITCH 30V DC  
89839 TANDEM PUMP

89836 STRAINING SCREW  
89827 WASHER  
89818 HYDRAULIC MOTOR  
89817 TURNBUCKLE SLEEVE  
89802 DOOR RH  
89741 ROD END BALL JOINT  
89740 BUSH RUBBER-METAL  
89735 AUGER-SECTION  
89734 AUGER-SECTION  
89704 PIPE  
89688 HOLDER SYSTEM  
89685 SEALING RUBBER  
8967 RIDER, LARGE  
89667 HOLDER  
8965 RIDER, SMALL  
89636 SOCKET INSERT  
89635 PLUG INSERT (CCC)  
89623 SET OF SEALS  
89593 BEARING  
89565 DRUM BEARING  
89502 DRUM FB500 HT5 LA6  
89501 FUSE  
89415 OVER-CENTER VALVE  
89414 PROPORTIONAL VALVE  
8939 BOLT  
8938 SCREW  
89378 MAIN AIR FILTER  
89377 SAFETY AIR FILTER  
89358 PUMP SUPPORT  
89353 SOLENOID VALVE  
89340 TEMPERATURE SWITCH  
8932 SCREW  
89306 THREADED PIN  
8930 SCREW  
8929 PADLOCK  
89286 RETAINING PLATE  
89274 STRIP  
8926 SCREW  
8924 AIR HOSE  
89230 COVER SHEET  
8923 SPECIAL TOOL  
8922 SLAG HAMMER  
89208 WELDING ELECTRODES  
8916 SCREW  
8915 SCREW  
89144 BOLT  
8914 SCREW  
8913 SCREW  
8909 SQUARE PIPE  
89085 DIRECTIONAL VALVE  
89084 FLOW DIVIDER  
89083 FLOW DIVIDER  
89072 STRUT HT2  
89071 STRUT HT2  
89067 PLUG-IN JUMPER  
89062 RELAY MODULE 24V DC  
89061 GEARBOX  
89048 HOLDER  
89044 FRONT BEARING  
8902 RUBBER ELEMENT  
8899 STRIP  
8898 STRIP  
88909 BOLT  
88896 ROLL HOLDER  
88885 PROTECTING SWITCH  
8888 SCREW  
88875 INSULATION PLATE

88775 FEEDING PRESSURE  
88774 SHAFT SEAL  
88757 MALE STUD COUPLING  
8868 SCREW  
88534 PRESSURE-RELIEF  
88532 SET OF SEALS  
88500 MOUNTING FLANGE  
8838 SCRAPER FB50  
8836 EJECTION DEVICE  
8835 EJECTION DEVICE  
8834 EJECTION DEVICE  
88333 CIRCUIT BREAKER  
8833 EJECTION DEVICE  
8829 FUEL PUMP  
8825 SCREW  
88243 NOZZLE BAND HEATER  
88242 NOZZLE BAND HEATER  
88241 NOZZLE BAND HEATER  
88240 NOZZLE BAND HEATER  
8824 SCREW  
88223 DISTRIBUTOR BLOCK  
88220 SPIRAL RING  
88219 SET OF SEALS  
88218 SPIRAL RING  
88217 O-RING SEAL  
88215 O-RING SEAL  
88214 O-RING SEAL  
88213 O-RING SEAL  
88212 OUTER DISC  
88211 INNER DISK  
88153 CABIN WINDOW  
8814 HYDRAULIC CYLINDER  
8813 HYDRAULIC CYLINDER  
88125 LOWER HOUSING  
88124 CONNECTOR INSERT  
88122 PIPE SOCKET  
8799 STRAIGHT PIN  
8798 THREADED PIN  
8796 FEATHER KEY  
8793 SCREW  
8791 SCREW  
87885 O-RING SEAL  
87868 WATER FILTER INSERT  
87867 WATER FILTER  
87866 HYDRAULIC CYLINDER  
87862 SCRAPER BLADE  
8784 EJECTION DEVICE  
8783 EJECTION DEVICE  
8782 EJECTION DEVICE  
87808 ELECTRICAL CABINET  
87770 LED BOARD 10-30V  
87769 FEMALE PLUG  
87713 ADJUSTABLE STUD  
87712 SEALING  
87711 FEMALE PLUG 24V  
87709 GEARBOX  
87708 SHAFT SEAL  
87705 FRONT IDLER  
87700 ADJUSTABLE EQUAL TEE  
87692 BURNT PART  
87683 BELT ROLLER  
87682 SUPPORTING ROLLER  
87667 WIPER RUBBER  
87666 FLANGE  
87665 DISTANCE PLATE  
87639 OPEN-END SPANNER 11  
87638 OPEN-END SPANNER 36



87637 OPEN-END SPANNER 32  
87636 OPEN-END SPANNER 30  
87635 OPEN-END SPANNER 29  
87634 OPEN-END SPANNER 27  
87633 OPEN-END SPANNER 26  
87632 OPEN-END SPANNER 24  
87631 OPEN-END SPANNER 23  
87630 OPEN-END SPANNER 22  
87629 OPEN-END SPANNER 21  
87620 AUGER  
87619 STATOR  
87617 TWIN PIPE NIPPLE  
8755 TENSION SPRING  
8754 FORK HEAD  
8753 FLEXIBLE STEEL TUBE  
8752 STRAIGHT PIN  
8751 SCREW  
8746 LOCKING SCREW  
8742 LAMPHOLDER WITH  
8737 PROTECTIVE CAP  
8730 HYDRAULIC HOSE  
8729 HYDRAULIC HOSE  
8728 HYDRAULIC HOSE  
8724 BUNG  
8719 O-RING SEAL  
8718 O-RING SEAL  
8717 O-RING SEAL  
8716 O-RING SEAL  
8715 O-RING SEAL  
8704 BALL JOINT  
8703 SYSTEM CLIP  
8702 BALL-JOINT COMPL  
8700 SCREW  
86999 FLUSH VALVE  
86998 RESISTOR  
8699 CASTEL NUT  
86955 LOGO BLACK GREY  
86912 HOLDER  
8690 UNION NUT  
8689 HOSE SUPPORT  
8688 GREASING NIPPLE  
8687 LOCKING SCREW  
8686 REDUCING ADAPTOR  
86824 OPEN-END SPANNER 20  
86823 OPEN-END SPANNER 19  
86822 OPEN-END SPANNER 18  
86821 OPEN-END SPANNER 17  
86819 OPEN-END SPANNER 16  
86818 OPEN-END SPANNER 15  
86817 OPEN-END SPANNER 14  
86816 OPEN-END SPANNER 13  
86815 OPEN-END SPANNER 12  
86814 OPEN-END SPANNER 10  
86813 OPEN-END SPANNER 8  
86812 OPEN-END SPANNER 6  
8680 THREADED PIN  
86799 EXTERNAL VIBRATOR  
86793 INSULATION PLATE  
86785 CRIMP RING CONNECTOR  
86784 CRIMP RING CONNECTOR  
86783 CRIMP RING CONNECTOR  
86772 WIRE ROPE  
86766 BURNT PART  
86750 SAW BLADE FB19  
86738 MANUAL PUMP  
8667 SPRINKLING MILL  
8651 GREASING NIPPLE

86499 SCREW  
86498 BEARING  
86496 AXIAL FACE SEAL  
8648 SET OF SEALS  
86474 SEAL  
86472 SEAL  
8647 PADLOCK  
86441 LEVER  
86434 SLEWING ARM  
86430 WATER PUMP  
86428 KEY  
86427 DOOR LOCK WITH KEY  
86403 SEAL  
86402 SEAL  
86336 CABLE HARNESS  
86335 CABLE HARNESS  
8632 TENSION PULLEY  
86282 SCRAPER BLADE B 224 R  
86252 SOCKET  
86250 CLIP  
86249 DIAPHRAGM...  
86247 CONTACTOR RELAY 24V  
86195 SCRAPER BLADE B 198 R  
86186 EJECTOR RUBBER  
8615 SCREW  
86142 STRIP  
8614 RING CONNECTOR  
86139 LOGO BLACK GREY  
86104 LEVEL MONITORING 12/24V DC  
86100 TERMINAL  
86094 FREQUENCY DIVIDER 1  
86079 HOSE CLAMP  
86047 THREADED ROD  
86007 INSULATION PLATE  
85974 CONTACTOR RELAY 24V  
85973 FUSE AUTOMAT (CCC)  
85971 ELECTRICAL CABINET  
85968 REDUCING ADAPTOR  
85967 NOZZLE  
85966 NON-RETURN VALVE  
85965 ADJUSTABLE STUD  
85961 GEARBOX  
85960 GEARBOX  
85958 GEARBOX  
85953 VALVE  
85921 HOUSING TOP PART  
85920 OVER-CENTER VALVE  
8592 SET OF SEALS  
8590 SHAFT JOINT  
8589 FEATHER KEY  
8588 GREASING NIPPLE  
8587 SPACER BUSH  
85855 WATER PUMP  
85851 SOLENOID COIL  
8585 SHAFT SEAL  
85847 COUPLING  
85844 HYDRAULIC CYLINDER  
85843 PRESSURE-RELIEF  
85842 BITUMEN PUMP  
85841 WATER PUMP  
8583 LOCKING LINK  
85821 CABIN WINDOW  
85820 CABIN WINDOW  
85819 WASHER  
85815 DIRECTIONAL CONTROL  
85814 PNEUMATIC CYLINDER  
8580 SCREW

85753 DUMMY PLUG  
85746 SET OF CABLES  
85744 FAN  
85743 FILTER  
85742 FRAME  
85741 FILTER GAUZE  
85740 TEMPERATURE  
85739 KIT  
85702 PLUG  
8570 CHAIN  
85696 BALL VALVE  
85691 FILTER INSERT  
85663 SOUND ABSORBER  
85572 WASHER  
85571 NOZZLE  
8555 GROOVED BALL BEARING  
85525 STICKER  
8547 BLIND PLUG  
85463 COVER  
85441 WASHER  
8542 ROD STEEL  
85419 GAS SPRING  
8540 SCREW  
85362 NON-RETURN VALVE  
85361 KEY  
85358 HYDRAULIC HOSE  
85357 HYDRAULIC HOSE  
85356 HYDRAULIC CYLINDER  
85355 CABIN WINDOW  
85353 PRESSURE REDUCTION  
85349 LOCKING SCREW  
85348 TENSION SPRING  
8530 TOOLBOX COMPL  
85299 BOLT  
85287 SOUND ABSORBER  
85284 SOUND ABSORBER  
85280 PRECLEANER  
85271 SET OF HOSES  
85252 SERVICE SET KEY  
85251 SERVICE SET O-RINGS  
85249 SERVICE SET  
85186 POLY GRIP PAD KIT W1  
85118 ROTARY LOCK  
85114 BEARING FLANGE  
85108 THREADED ROD  
85090 CONNECTION PIECE  
85089 HOLDER  
85087 TENSION ADJUSTER  
85006 COUPLING HEAD  
84930 TWIN PIPE NIPPLE  
84897 AUGER 0,712M LEFT  
84896 AUGER 0,725M RIGHT  
84871 DOG PLATE  
84870 COUPLING  
84841 BITUMEN NOZZLE  
84837 FILTER INSERT  
84815 SOLENOID COIL  
84814 FRONT ELEMENT  
84813 SILENCER  
84811 SHAFT SEAL  
84810 SPUR WHEEL  
84809 SPUR WHEEL  
84808 SPUR WHEEL  
84807 SPUR WHEEL  
84805 SHAFT SEAL  
84803 LOCKING SCREW  
84802 COVER

8477 SCREW  
8473 WIPER RUBBER  
84648 TARPAULIN  
84643 ALLAN KEY 17  
84642 ALLAN KEY 6  
84641 SPACER WASHER  
84640 HYDRAULIC HOSE  
84639 HYDRAULIC HOSE  
84636 HYDRAULIC HOSE  
84635 HYDRAULIC HOSE  
84634 HYDRAULIC HOSE  
84633 HYDRAULIC HOSE  
84632 HYDRAULIC HOSE  
84582 COVER  
84581 RING  
84443 SCREW  
84407 WASHER  
84393 O-RING SEAL  
84388 HYDRAULIC PUMP  
84387 HYDRAULIC PUMP  
84385 THREADED PIN  
84383 TRANSITION PIECE  
84382 HOSE COUPLING  
84380 SET OF SEALS  
84379 FUEL FILTER  
84365 DRESSER UNIT  
84342 RUBBER RING  
8432 STEEL BRUSH  
84317 RACK AND PINION JACK  
8431 REDUCING BUSH  
84252 PNEUM. EJECTOR  
84251 PNEUM. DRIVER FOR  
84222 PLUG 24V  
84221 HYDRAULIC CYLINDER  
84216 WIPER MOTOR  
84215 BALL HANDLE  
84214 COUPLING  
84213 RING  
84193 OVERHANG INDICATOR  
84155 STRIP  
84153 STRIP  
84143 SCRAPER STRIP  
84129 MANUAL PUMP  
84128 FUEL FILTER  
84126 INJECTION PUMP  
84124 PIPE CLIP  
84122 JOINT PLATE  
8412 PIPE  
84080 EXTENSION SOCKET  
84051 THREADED ROD  
84022 TENSION WEDGE  
84011 BALL VALVE  
84007 PIPE  
84004 PIPE  
8400 FEATHER KEY  
83982 CABLE HARNESS  
8398 FEATHER KEY  
83972 CABLE  
83971 BATTERY CABLE 24V  
83970 BATTERY CABLE 24V  
83969 BATTERY CABLE 24V  
8393 FEATHER KEY  
8392 FEATHER KEY  
83915 BOLT  
83914 BOLT  
8391 FEATHER KEY  
83908 ANGLE

83907 ANGLE  
83893 BURNT PART  
83889 WASHER  
8387 FEATHER KEY  
8385 FEATHER KEY  
8383 CONVEYOR STRAP  
83780 AUTOMATIC SHUTOFF  
8378 GROOVED BALL BEARING  
8374 BELT CLEANER ROLLER  
83724 STICKER  
83675 INSULATION PLATE  
8363 SUPPORT IDLER B400  
8362 SUPPORT IDLER B400  
83608 SOUND ABSORBER  
83606 SOUND ABSORBER  
8357 HYDRAULIC MOTOR  
8353 BELT ROLLER  
8351 DIRECTIONAL VALVE  
83505 TENSION SPRING  
83504 SCREW  
83503 SCREW  
8350 SCREW  
83499 O-RING SEAL  
83494 SEALING LAMELLA  
83493 CLAMPING SLEEVE  
83452 CABLE HARNESS  
83451 LEVEL MONITORING 12  
83449 ALARM HORN  
83448 POLE CAP, RH  
83447 POLE CAP, LH  
83424 SPHERICAL ROLLER  
83423 PRECLEANER  
83421 3-FASE CURRENT  
83420 3-FASE CURRENT  
83417 CONNECTING BLOCK  
83416 PROTECTING SWITCH  
83415 PROTECTING SWITCH  
83414 SWITCH BLOCK  
83413 PROTECTING SWITCH  
83412 PROTECTING SWITCH  
83406 FRAME  
83404 ACRYLIC GLASS SCREEN  
8340 CLAMPING SLEEVE  
8339 CLAMPING SLEEVE  
8338 CLAMPING SLEEVE  
8335 CLAMPING SLEEVE  
8334 CLAMPING SLEEVE  
83339 STRIP  
8333 CLAMPING SLEEVE  
8330 CLAMPING SLEEVE  
83288 LOCK NUT  
83283 SEALING  
83280 FLANGE  
8328 CLAMPING SLEEVE  
83279 MOUNTING FIXTURE  
8327 CLAMPING SLEEVE  
8321 CLAMPING SLEEVE  
8320 CIRCLIP  
8319 CIRCLIP  
8318 CIRCLIP  
8317 STRAIGHT PIN  
8316 FEATHER KEY  
8315 FEATHER KEY  
8312 CASTEL NUT  
8311 SPLIT PIN  
83068 PIPE  
83015 HOUSING (CCC)

83014 PROTECTING SWITCH  
83013 O-RING SEAL  
83012 DIAPHRAGM  
83005 HYDRAULIC CYLINDER  
82958 BAR  
82955 HOLDER  
8288 CONVEYOR BELT  
8287 CONVEYOR STRAP  
82859 STRIP  
8283 FUSE  
8282 BOLT  
82811 WIPER RUBBER  
82805 WEAR SHEET  
8280 BOLT  
82799 BURNT PART  
82798 ROLL HOLDER  
82797 ROLL HOLDER  
82796 WIPER RUBBER  
82795 SEAL  
82794 WIPER RUBBER  
82793 LID  
82792 HOUSING  
82791 LATERAL PLATE  
82790 LATERAL PLATE  
82786 LATERAL PLATE  
82783 LATERAL PLATE  
82781 SCRAPER  
8278 BOLT  
8277 OIL FILTER CARTRIDGE  
82755 CORRECTING  
8275 SUPPORT  
82747 EJECTOR DRIFT FOR  
82746 EJECTION DEVICE  
82745 LOGO BLACK GREY  
82734 STICKER  
82733 STICKER  
82631 INSTRUMENT BOARD  
82610 ROPE PULLEY  
82584 COVER  
82578 MIRROR-RETAINER  
82570 OPEN-ENDED SPANNER  
82568 GUIDE BEAM  
82567 GUIDE BEAM  
82566 GUIDE BEAM  
82562 THREADED ROD  
82561 SEPARATING PLATE  
82560 BRACING  
8256 SCREW  
82555 STICKER  
82554 STICKER  
82553 STICKER  
82552 NON-RETURN VALVE  
82551 O-RING SEAL  
82550 HYDRAULIC PUMP  
82545 HYDRAULIC CYLINDER  
82544 FLANGED BEARING  
82543 FLANGED BEARING  
82451 WIPER RUBBER  
82449 HOLDER  
82442 BURNT PART  
8240 LADDER RUNG  
8237 WIRE ROPE  
82283 BOLT  
82252 FRONT ELEMENT  
82250 BENT TUBE  
82246 GAS SPRING  
82243 OUTER DISC

82238 STRUT  
82237 STRUT  
8222 SCREW  
82214 HYDRAULIC CYLINDER  
82213 JOINT HEAD  
82212 HEXAGONAL NUT  
82211 MAGNETIC BRACKET  
82210 BUTTON  
8221 SCREW  
82209 RUBBER SPOUT  
82203 MALE STUD COUPLING  
8220 SCREW  
8219 SCREW  
82189 REDUCING SLEEVE  
82187 TWIN PIPE NIPPLE  
8218 SCREW  
8217 SCREW  
8216 SCREW  
8215 SCREW  
8214 SCREW  
8213 SCREW  
82120 CONSOLE  
82119 DISPLAY BOARD  
82115 INSTRUMENT BOARD  
8211 SCREW  
8210 SCREW  
82099 LID  
8209 SCREW  
82074 ROTARY ENCODER  
82055 WASHER  
82052 SHAFT SEAL  
82051 HYDRAULIC HOSE  
82050 PROFILED BUSH  
82048 FEELER GAUGE  
82046 SCREW  
82045 SCREW  
82044 SENSORING TUBE  
82043 SENSORING ARM  
82041 COUPLING  
82040 COUPLING  
82036 WEAR SHEET  
82018 GROOVED BALL THRUST  
81915 SPRAYING  
81913 CONTROL UNIT  
81865 FORK  
81858 BAR  
81850 SCREW  
81843 HYDRAULIC HOSE  
81840 BLIND RIVET NUT  
81838 BANJO COUPLING, ONE  
81836 DRIVER'S SEAT  
81812 LADDER  
81791 HYDRAULIC HOSE  
81779 CONDUIT BOX  
81777 LOWER HOUSING  
81776 PLUG INSERT (CCC)  
81775 CONNECTOR INSERT  
81774 HOUSING TOP PART  
81771 PLC UNIT COMPLETE  
81745 FOOTSTEP  
81725 HAND-RAIL  
81658 RUBBER  
81657 RUBBER  
81596 ELECTRICAL CABINET  
81576 HOLDER  
81569 ROD STEEL  
81564 DRUM FB300+2X25 HT4

81512 HYDRAULIC MOTOR  
81510 HEXAGONAL NUT  
81507 SET OF SEALS  
81504 LID  
81503 CONTROL KNOB  
81499 MALE STUD COUPLING  
81497 THROTTLE CONNECTOR  
81496 JOINT PLATE  
81475 PUSH-ROD  
81413 ADAPTER  
8139 LOCKING SCREW  
81371 CONNECTION PIPE  
81363 FLANGE  
81359 OIL COOLER  
81357 LOGO BLACK GREY  
81356 LOGO BRIGHT GREY  
81350 THROTTLE-FREE ANG  
8130 O-RING SEAL  
81290 STRIP  
8129 O-RING SEAL  
81273 FRONT ELEMENT  
81270 COUPLING RING  
81269 TOWING COUPLING  
81268 SQUARE PIPE  
81264 SOLENOID COIL  
81262 PIPE CLIP  
81261 COMPRESSOR 24V  
81259 JOINT HEAD  
81258 GAS SPRING  
8120 O-RING SEAL  
8119 O-RING SEAL  
8118 O-RING SEAL  
8117 O-RING SEAL  
81165 THREADED ROD  
8116 O-RING SEAL  
8115 O-RING SEAL  
8114 O-RING SEAL  
8113 O-RING SEAL  
81097 SCALE  
81090 OVERHANG INDICATOR  
81086 SCREW  
81081 RESISTOR  
81080 SUB-D CONNECTOR  
81077 BASIC UNIT  
81071 HYDRAULIC PUMP  
81060 SLEWING BOW  
81059 BOW  
8100 ANGLE  
8099 ANGLE  
80980 RUBBER  
8098 TWIN PIPE NIPPLE  
80978 STEP  
80951 ENGINE FLANGE  
8092 SCREW  
80877 STUD STANDPIPE  
80876 MANUAL PUMP  
80875 HYDRAULIC HOSE  
80874 HYDRAULIC HOSE  
80866 RUBBER BEND  
80865 COMPENSATOR  
80864 SET OF SEALS  
80860 PLUG  
8086 BULB 24V DC  
80858 WINDSHIELD RUBBER  
8085 BULB 24V DC  
80847 LADDER  
80819 ADAPTER



80771 STICKER  
80770 STICKER  
80742 CONTAMINATION...  
80741 HYDRAULIC OIL FILTER  
80739 VIBRATING MASS  
80737 HYDRAULIC HOSE  
80736 HYDRAULIC HOSE  
80735 HYDRAULIC HOSE  
80733 HYDRAULIC HOSE  
80729 STICKER  
80728 STICKER  
80725 ADAPTER PLATE  
80724 GUSSET  
80723 GEAR PLATE  
80722 BURNT PART  
80718 KIT  
80714 HYDRAULIC PUMP  
80709 HOLDER  
80680 PIPE  
80678 HYDRAULIC HOSE  
80677 HYDRAULIC HOSE  
80674 HYDRAULIC HOSE  
80673 HYDRAULIC HOSE  
80672 HYDRAULIC HOSE  
80671 HYDRAULIC HOSE  
80670 HYDRAULIC HOSE  
80669 HYDRAULIC HOSE  
80668 HYDRAULIC HOSE  
80667 HYDRAULIC HOSE  
80666 SCREW  
80665 PLUG  
80663 SET OF SEALS  
80655 SEALING RUBBER  
80647 IMPACT SHEET  
80611 MULTIMETER  
80607 SHAFT SEAL  
80606 LOCKING RING  
80603 BULKHEAD COUPLING  
80602 BANJO COUPLING,ONE  
80601 HYDRAULIC HOSE  
80597 HYDRAULIC HOSE  
80593 BEARING FLANGE  
80565 FELT PACKING  
80564 CIRCLIP  
80533 HYDRAULIC CYLINDER  
80532 HAND-RAIL  
80521 BENT PART  
80519 BURNT PART  
80508 BENT PART  
80502 BURNT PART  
80498 DISTANCE SHEET  
80493 HOLDER  
8049 SHACKLE  
80483 HOLDER  
80482 LOCKING BAR  
8045 PIPE FITTING  
8044 TWIN PIPE NIPPLE  
80424 CLIP  
8042 FLANGED BEARING  
80419 STAY BAR  
80412 GUIDE BAR  
80410 PLATE  
8040 O-RING SEAL  
80397 BOLT  
80396 BOLT  
80394 BOLT  
80392 ADAPTER

80391 CLIP  
80390 DIRECTIONAL CONTROL  
80389 CONNECTION PLATE  
80374 TAIL PIPE  
80373 BOLT  
80372 BOLT  
80371 BOLT  
80370 BOLT  
80356 SILENCER  
80355 BOLT  
80354 COMPENSATOR TUBE  
80353 COMPENSATOR TUBE  
80332 ENGINE MOUNTING  
80314 SUPPORT SHEET  
8031 WIRE CLIP  
80305 CONNECTION ELEMENT  
80304 ADAPTER  
80300 HOLDER  
80299 BEARING SHAFT  
80292 TENSIONER ARM  
80290 HOLDER  
8028 WIRE CLIP  
80271 TANK CAP  
80270 STEERING COLUMN  
8027 WIRE CLIP  
80267 SCREW  
80260 TYRE VALVE  
8026 WIRE CLIP  
80255 BURNT PART  
8025 WIRE CLIP  
80249 CYLINDRICAL HOLDING  
80237 MOUNTING FIXTURE  
80235 BURNT PART  
80221 BALL JOINT  
80210 TRACK ROD  
80205 SUSPENSION LINK  
80156 CONNECTION ELEMENT  
80151 BEARING BLOCK  
8015 HORN 24V DC  
8014 PLUG 12V  
80135 BOLT  
8012 PLUG 6V-24V  
80117 STRIP  
80112 WIPER RUBBER  
80092 SCRAPER BLADE  
80033 SCREW  
80032 SCREW  
80031 SCREW  
80028 V-BELT PULLEY  
80025 HYDRAULIC CYLINDER  
80022 HYDRAULIC MOTOR  
80017 TYRE  
79998 RETAINER SCREW HT3  
79997 PICK SUPP.BASE  
79996 PICK SUPP.BASE SECT  
79995 PICK SUPP.BASE SECT  
7998 THERMOMETER  
79972 GLASS-FUSE  
79961 PLC UNIT COMPLETE  
7996 AMMETER  
7993 RELAY 24V DC  
7991 RELAY 24V DC  
7990 RELAY 24V DC  
7989 RELAY 12V DC  
79863 SPARE PART CPU  
79859 PLC UNIT COMPLETE  
79857 FRAME

79855 SAW BLADE FB14  
79847 WEAR SHEET  
79834 BASIC HOUSING  
79831 HYDRAULIC CYLINDER  
7983 PLUG SOCKET 12V  
79827 SHAFT SEAL  
7982 PLUG SOCKET 24V  
7981 FUSE BOX 24V  
79801 CONDUIT BOX  
7980 FUSE BOX 24V  
79798 BOWDEN CABLE  
79796 EMERGENCY STOP  
7979 RUBBER SPOUT  
7977 BLIND PLUG  
7976 THUMB NUT  
7975 SCREW  
7965 RETAINING SHEET  
7963 STRIP  
79613 AUGER 0,35M RIGHT  
7955 STRIP  
79527 STICKER  
79526 RUBBER ELEMENT  
79525 RAIN CAP  
79511 CABLE HARNESS  
79510 HOUSING  
79509 INSTRUMENT BOARD  
79450 GUIDING BUSH  
79406 STICKER  
79405 STICKER  
79404 STICKER  
79390 TROUGH  
79364 DIODE RAILING  
79354 GEARBOX  
79353 GEARBOX  
79352 HYDRAULIC HOSE  
79350 LEVEL SWITCH 24V  
79349 OVERHANG INDICATOR  
79348 PROXIMITY SWITCH  
7928 FEATHER KEY  
79271 INTERMEDIATE PLATE  
7927 FEATHER KEY  
79268 INTERMEDIATE PLATE  
79263 PULLEY COATING  
7925 CLAMPING SLEEVE  
7922 SCALE  
7920 SHIFT LEVER  
7918 ANGLE JOINT  
79142 STROKE SOLENOID  
79141 STARTER 24V DC  
79140 V-BELT  
7914 TEMPERATURE...  
7913 SERVICE HOUR METER  
79129 HYDRAULIC PUMP  
79128 HYDRAULIC PUMP  
7912 IGNITION KEY  
7911 PRESSURE SWITCH 6  
79109 LID  
79103 ADAPTER  
79102 SIDE PLATE  
7909 PLUG SOCKET 12V/24V  
7908 SWITCH 28V  
7907 TENSION SPRING  
7906 LENTICULAR SEAL  
79055 BACK-UP MODULE  
79053 ROTARY ENCODER  
79051 TERMINAL  
79042 INSTRUMENT BOARD

79036 STRAINING SCREW  
79024 RETAINING RING  
79023 RETAINING RING  
79022 RETAINING RING  
79021 RETAINING RING  
79018 O-RING SEAL  
79017 O-RING SEAL  
79010 SET OF SEALS  
78962 ADAPTER  
7893 SPRING PIN  
78928 COVER  
7892 SPRING PIN  
7891 SPRING PIN  
7890 SPRING PIN  
7889 SPRING PIN  
7888 SPRING PIN  
78841 FRAME JOINT FOR HOOD  
78836 SEALING RUBBER  
78825 SEAL  
78823 SEAL  
78731 INTERMEDIATE FLANGE  
78711 GAS SPRING  
78661 HEXAGONAL NUT  
7866 SCREW  
78659 NON-RETURN VALVE  
78657 SET OF SEALS  
78653 FRICTION BEARING  
7865 SCREW  
78600 SOUND ABSORBER  
7857 SCREW  
78569 SAW BLADE FB14  
7856 SCREW  
78556 PICK SUPPORT HT06  
78545 SIDE PLATE  
78523 STRIP  
7851 SCREW  
7850 SCREW  
7849 SCREW  
7848 SCREW  
7845 SCREW  
7843 SCREW  
7837 SEALING RING  
78334 HEX SOCKET 32MM-3/4  
78332 DEKORBAND  
78331 ALTERNATOR 28V DC  
78330 HYDRAULIC HOSE  
78329 TANDEM PUMP  
7831 SHAFT SEAL  
78294 SEAL  
78292 GUIDANCE  
7829 SEALING RING  
78289 SEAL  
78287 EDGE PROTECTION  
78278 STICKER  
78277 STICKER  
78275 HOLDER SYSTEM  
78274 SEALING RUBBER  
7827 SHAFT SEAL  
78246 OIL PRESSURE SENSOR  
78242 COMPENSATOR  
78241 SEALING KIT CPL  
78237 PRESSURE-RELIE  
78236 FILTER INSERT  
78189 JOYSTICK  
78188 CONTROL STICK  
78164 SHAFT SEAL  
78163 AUTOMATIC CONTROLLER

78162 MALE STUD COUPLING  
78161 MALE STUD COUPLING  
78160 HYDRAULIC HOSE  
78159 HYDRAULIC HOSE  
78152 SPADE CHISEL  
78151 POINTED CHISEL  
78150 FLAT CHISEL  
78148 NON-RETURN VALVE  
78147 V-BELT  
78146 V-BELT  
78144 TEMPERATURE SWITCH  
78143 OIL PRESSURE SWITCH  
78142 SET OF SEALS  
78045 LAMELLAR PLUG  
78043 MALE STUD COUPLING  
78041 DUST CAP  
78040 DUST CAP  
78039 COUPLING SOCKET  
78038 COUPLING PLUG  
78036 HYDRAULIC PUMP  
78035 HYDRAULIC PUMP  
78034 HYDRAULIC PUMP  
78033 SEALING KIT CPL  
7802 SEALING RING  
78010 ALUMINIUM SIGN  
78007 SET OF STICKERS  
78006 SET OF STICKERS  
77966 WASHER  
77948 WASHER  
77939 CONDUIT BOX  
77934 STRIP  
77926 PIPE  
77924 TERMINAL  
77922 HOLDER  
7792 SHAFT SEAL  
77918 U-PROFILED STEEL  
77909 SOUND ABSORBER  
77892 EJECTOR BLOC  
77871 FLANGE  
77870 BURNT-OUT TEMPLATE  
77864 SCREW-ON PLATE  
77861 SCRAPER BLADE  
7785 SCRAPER  
77842 FORK WRENCH  
77841 PADLOCK  
77840 WASHER  
77825 SEALING RUBBER  
77728 STRAP  
7771 SHAFT SEAL  
7767 SHAFT SEAL  
77657 DEPTHFORM  
7765 SHAFT SEAL  
77625 PIPE  
77620 COUPLING  
7762 SHAFT SEAL  
77619 SWITCH CONNECTOR  
77617 SCREW  
77587 VAPORIZER  
77584 ADAPTER  
7754 SHAFT SEAL  
7750 SHAFT SEAL  
77484 EDGE PROTECTION  
77479 SCRAPER BLADE  
7746 SHAFT SEAL  
77451 RETAINER SCREW  
7745 SHAFT SEAL  
77448 HYDRAULIC HOSE

77444 THREADED ROD  
7744 SHAFT SEAL  
7739 SQUARE PIPE  
77387 STRIP  
7736 BALL HANDLE  
7735 BALL HANDLE  
77348 TEMPERATURE SWITCH  
77347 SET OF SEALS  
77346 OIL PRESSURE SWITCH  
77345 AIR PRE-CLEANER  
77343 WIRE CLIP  
77341 HOUSING BASE PART  
7734 BALL HANDLE  
77339 SAFETY AIR FILTER  
77338 FUEL FILTER  
77330 SOUND ABSORBER PLATE  
77328 SOUND ABSORBER PLATE  
77327 SOUND ABSORBER PLATE  
77326 SOUND ABSORBER PLATE  
77325 SOUND ABSORBER PLATE  
77324 SOUND ABSORBER PLATE  
77323 SOUND ABSORBER PLATE  
7732 INDICATOR LAMP 24V  
7731 INDICATOR LAMP 24V  
7730 INDICATOR LAMP 24V  
77283 SLIDE  
77282 HOLDER  
77281 LEVER  
77238 SET OF SEALS  
77196 LADDER  
77142 CRIMP FERRULE WITH  
77137 ANGLE  
77136 T-PIECE  
77133 VALVE BLOCK  
77132 DIRECTIONAL  
77108 BOLT  
77092 CAM  
77091 BOLT  
77089 SCALE BRACKET  
77087 SEALING WASHER  
7708 DIAPHRAGM  
7707 CONTROL KNOB  
77059 WASHER  
77055 BEARING SHAFT  
77053 TENSION PULLEY  
77052 V-BELT PULLEY  
77051 V-BELT PULLEY  
77050 POWER BELT COMPOUND  
7705 PEDESTAL BEARING  
7702 CYLINDRICAL ROLLER  
77005 IDLER UNIT  
77003 HYDRAULIC MOTOR  
77002 DISC RING  
7700 HYDRAULIC CYLINDER  
76985 SPREADER AUGER, LEFT  
7698 SCREW  
76959 HOLDER  
76958 STRIP  
76904 STROKE SOLENOID  
76903 V-BELT  
76902 V-BELT  
76687 SPINDLE  
76686 SPINDLE  
76682 CABLE HARNESS  
76670 CABLE SENSOR  
76651 SET OF SEALS  
76650 CLUTCH INSERT

76649 PROTECTION GLOVES  
76648 FORK HEAD  
76646 ROTARY SWITCH 5V  
76645 HOUSING  
76644 CIRCLIP  
76642 HYDRAULIC CYLINDER  
7656 SCREW  
7654 RETURN PULLEY B400  
7651 SQUARE PIPE  
76508 PIVOT POINT  
76495 AIR FILTER ELEMENT  
76494 MAIN AIR FILTER  
76493 RUBBER BEND  
76492 AIR FILTER HOUSING  
76491 GEARBOX  
76490 GEARBOX  
76487 SCREW  
76486 HEXAGONAL NUT  
76484 RESISTOR  
76477 EJECTOR RUBBER  
76476 STRIP  
76471 SOUND ABSORBER  
76468 INSULATION PLATE  
76467 INSULATION PLATE  
76466 INSULATION PLATE  
76465 INSULATION PLATE  
7644 AXLE SUSPENSION  
76379 LID  
76378 BEARING FLANGE  
76362 KIT  
76361 INTERMEDIATE PIECE  
76345 INSULATION PLATE  
76344 INSULATION PLATE  
76343 INSULATION PLATE  
76342 INSULATION PLATE  
76341 INSULATION PLATE  
76340 INSULATION PLATE  
76339 INSULATION PLATE  
76332 INTERMEDIATE PIPE  
76309 REVOLUTION SENSOR  
76306 THREADED BOLT  
76301 SET OF SEALS  
76300 HYDRAULIC CYLINDER  
76298 STRAIN WASHER  
76297 SCREW  
7629 SHAFT  
76184 HINGE  
76077 SLIDE  
76072 CONSOLE  
76014 BURNT PART  
75990 SCREW  
75989 SET OF SEALS  
75915 BURNT PART  
75912 BURNT PART  
75905 BOLT  
7590 PIPE  
75899 SCREW  
75898 MALE STUD COUPLING  
75892 JOINT PLATE  
75891 SOUND ABSORBER  
7588 TAPER ROLLER BEARING  
7587 PRESSURE-RELIEF  
7586 PIPE  
7585 PIPE  
75835 SCREW  
75833 SET OF SEALS  
75832 SET OF SEALS

75831 HYDRAULIC CYLINDER  
75830 REPAIR KIT F. HYD.  
75829 PUMP GEAR  
75828 PUMP HOUSING  
75826 HYDRAULIC CYLINDER  
75825 HYDRAULIC CYLINDER  
75819 DISTANCE TUBE  
75730 BRACKET  
75725 BATTERY CABLE 24V  
75722 VIBRATOR BENT  
75721 VIBRATOR STRAIGHT  
75659 PLUG BOX  
75658 PLUG BOX  
75657 HOUSING  
75632 GROOVED BALL BEARING  
75626 STICKER  
75619 STRIP  
75618 PROTECTING SHEET  
7561 CONNECTION PIPE  
75607 ENGINE FLANGE  
75535 SCREW  
75488 CABLE  
75486 SCREW LOCKING  
75448 COUPLING  
7542 PIPE  
75379 KIT  
75377 KIT  
7537 NOZZLE  
7535 SPRING PIN  
7534 SCREW  
75329 THROTTLE CONNECTOR  
7532 GAS SPRING  
75251 BOLT  
75209 STRIP  
75191 GAS SPRING  
75188 FLANGED BEARING  
75187 FLANGED BEARING  
75181 FOOT SWITCH  
75180 BIO-HYDRAULIC-OIL  
75179 HYDRAULIC HOSE  
75178 HYDRAULIC MOTOR  
75154 COMPRESSION SPRING  
75153 COMPRESSION SPRING  
7507 STRIP  
75038 CONVEYOR STRAP  
75030 STEERING UNIT  
75027 MANOMETER SELECTOR  
75026 MANOMETER  
75023 REAR LIGHT  
75022 REAR LIGHT  
75016 CAM SWITCH  
75005 SEALING WASHER  
74999 HEXAGONAL NUT  
74994 STRIP  
74993 SEALING RUBBER  
74991 HOLDER  
74936 BOLT  
74935 BOLT  
7486 FILLER NECK  
7485 TANK CAP  
74830 PIPE  
74813 WORKING TROUSERS  
74803 HOLDER  
74801 PICK SUPPORT HT2 170  
74800 PICK SUPP.BASE  
74799 BURNT PART  
74745 PICK SUPPORT HT5



74737 DRUM FB350 HT5 LA6  
74722 METAL PLATE  
74721 METAL PLATE  
74719 METAL PLATE  
74655 COUPLING  
74636 ROLL HOLDER  
74626 SOLID RUBBER TYRE  
74618 BOLT  
74592 THREADED ROD  
74582 RETAINER SCREW  
74573 PIPE  
74572 EXHAUST SILENCER SM  
74556 BOLT  
74534 BUSHING  
74533 STICKER